SENNHEISER

ew 100 G2

Instructions for use



Safety instructions

Never open electronic units! If units are opened by customers in breach of this instruction, the warranty becomes null and void.

Keep the units away from central heating radiators and electric heaters. Never expose them to direct sunlight.

Use the units in dry rooms only.

Use a damp cloth for cleaning the units. Do not use any cleansing agents or solvents.

Thank you for choosing Sennheiser!

We have designed this product to give you reliable operation over many years. Over half a century of accumulated expertise in the design and manufacture of high-quality electro-acoustic equipment have made Sennheiser a world-leading company in this field.

Please take a few moments to read these instructions carefully, as we want you to enjoy your new Sennheiser products quickly and to the fullest.

Contents

Safety instructions ... 2
Contents ... 3
The evolution wireless series ew 100 G2 ... 4
- The channel bank system ... 4

System variants ... 5
Overview of operating controls ... 6
- EM 100 G2 rack-mount receiver ... 6
- EK 100 G2 bodypack receiver ... 7
- SK 100 G2 bodypack transmitter ... 8
- SKP 100 G2 plug-on transmitter ... 9
- SKM 100 G2 radiomicrophone ... 10
- Indications and displays on the receivers ... 11
- Indications and displays on the transmitters ... 13

Preparing the components for use ... 14
- EM 100 G2 rack-mount receiver ... 14
- EK 100 G2 bodypack receiver ... 17
- SK 100 G2 bodypack transmitter ... 18
- SKP 100 G2 plug-on transmitter ... 19
- SKM 100 G2 radiomicrophone ... 20

Using the components ... 22
- Switching the components on/off ... 22
- Muting the transmitters ... 23
- Activating/deactivating the lock mode ... 23
- Attaching the components to clothing ... 24

The operating menu ... 25
- The buttons ... 25
- Overview of menus ... 25
- Working with the operating menu ... 26
- Operating menu of the receivers ... 27
- Operating menu of the transmitters ... 29

Adjustment tips for the operating menu ... 31
- Switching between channel banks ... 31
- Switching between the channels in a channel bank ... 31
- Selecting the frequencies to be stored in the channel bank "U" ... 31
- Scanning the channel banks for free channels (receivers only) ... 31
- Multi-channel operation ... 32
- Adjusting the sensitivity (transmitters only) ... 32
- Adjusting the audio output level (receivers only) ... 33
- Adjusting the squelch threshold (receivers only) ... 33
- Selecting the standard display ... 34
- Entering a name ... 34
- Loading the factory-preset default settings ... 35
- Activating/deactivating the pilot tone transmission or pilot tone evaluation ... 35
- Activating/deactivating the lock mode ... 35
- Exiting the operating menu ... 35

If problems occur ... 36
- Error checklist ... 36
- Recommendations and tips ... 37

Care and maintenance ... 38
Additional information ... 39
- HDX noise reduction ... 39
- Wireless transmission systems ... 40
- Squelch ... 40
- Diversity reception ... 41

Specifications ... 42
- Connector assignment ... 43
- Polar diagrams and frequency response curves of microphones/microphone heads ... 44

Accessories ... 45
Manufacturer declarations ... 46
- Warranty regulations ... 46
- CE Declaration of Conformity ... 46
- Batteries or rechargeable batteries ... 46
- WEEE Declaration ... 46

The evolution wireless series ew 100 G2

With the evolution wireless series ew 100 G2, Sennheiser offers musicians, video and sound amateurs high-quality state-of-the-art RF transmission systems with a high level of operational reliability and ease of use. Transmitters and receivers permit wireless transmission with studio-quality sound. The excellent transmission reliability of the ew 100 G2 series is based on the use of

- further optimized PLL synthesizer and microprocessor technology,
- the HDX noise reduction system,
- the pilot tone squelch control,
- the true diversity technology (rack-mount receiver only)
- and the scan function for scanning the channel banks for free channels.

The channel bank system

The ew 100 G2 systems are available in five UHF frequency ranges with 1440 transmission/receiving frequencies per frequency range. Please note: Frequency usage is different for each country. Your Sennheiser agent will have all the necessary details on the available legal frequencies for your area:

Range A: 518 to 554 MHz
Range B: 626 to 662 MHz
Range C: 740 to 776 MHz
Range D: 786 to 822 MHz
Range E: 830 to 866 MHz

Transmitters and receivers have nine channel banks with four switchable channels each.



The channel banks "1" to "8" have four switchable channels that are factory-preset to a transmission/receiving frequency (see enclosed frequency table). These transmission/receiving frequencies cannot be changed but have been preset so that e.g. country-specific regulations on frequency usage are taken into account. The channel bank "U" (user bank) has four switchable channels to store your selection out of 1440 transmission/receiving frequencies that are freely selectable within the preset frequency range.

An advantage of the factory-preset frequencies is that

- the systems are ready for immediate use after switch-on,
- several systems can be operated simultaneously on the preset channels without causing intermodulation interference.

System variants



EM 100 G2

EK 100 G2

SKM 100 G2

ME 4



SKP 100 G2

SK 100 G2

ME 3 headmic

ME 2

Areas of application

System	Areas of application
ew 112 G2	Theater, presentation (omni-directional)
ew 122 G2	Theater, presentation (high feedback rejection)
ew 152 G2	Sports (aerobic), vocals
ew 172 G2	Instruments
ew 135 G2	Speech, vocals
ew 145 G2	Vocals (high feedback rejection)
ew 165 G2	Vocals, presentation (high feedback rejection)
ew 100-ENG G2	Versatile system, camera-mounted applications
ew 112-p G2	Presentation, camera-mounted applications
ew 122-p G2	Noisy environments, camera-mounted applications
ew 135-p G2	Speech, vocals, camera-mounted applications

Delivery includes

System	EM 100 G2	EK 100 G2	SK 100 G2	SKP 100 G2	SKM 100 G2 with MD 835 mic head (dynamic, cardioid)	SKM 100 G2 with MD 845 mic head (dynamic, super-cardioid)	SKM 100 G2 with ME 865 mic head (condenser, super-cardioid)	ME 2 clip-on microphone (condenser, omni)	ME 3 headmic (condenser, super-cardioid)	ME 4 clip-on microphone (condenser, cardioid)	NT 2-1 mains unit	Batteries	Line output cable with jack plug	Line output cable with XLR-3 connector	2 telescopic antennas	Camera kit	Microphone clamp	Instrument cable	Instructions for use
ew 112 G2	X		X					X			X	2			X				X
ew 122 G2	X		X							X	X	2			X				X
ew 152 G2	X		X						X		x	2			X				X
ew 172 G2	X		X								X	2			X			X	X
ew 135 G2	X				X						X	2			X		X		X
ew 145 G2	X					X					X	2			X		X		X
ew 165 G2	X						X				X	2			X		X		X
ew 100-ENG G2		X	X	X				X				6	X	X		X			X
ew 112-p G2		X	X					X				4	X	X		X			X
ew 122-p G2		X	X							X		4	X	X		X			X
ew 135-p G2		X			X							4	X	x		X	X		X

Overview of operating controls

EM 100 G2 rack-mount receiver



Operating controls

1. LC display
2. ▲ button (UP)
3. ▼ button (DOWN)
4. SET button
5. POWER button
   (serves as the ESC (cancel) key in the operating menu)
6. Cable grip for power supply DC cable
7. DC socket for connection of mains unit (DC IN)
8. Audio output (AF OUT BAL),
   XLR-3M socket, balanced
9. Audio output (AF OUT UNBAL),
   ¼" (6.3 mm) jack socket, unbalanced
10. Service interface (DATA)
11. Antenna input II (ANT II), BNC socket
12. Type plate
13. Antenna input I (ANT I), BNC socket

LC display panel

① Display for the current channel bank "1 ... 8, U"

② Display for the current channel number "1 ... 4"

③ "B.CH" – abbreviation for channel Bank and CHannel number

④ Alphanumeric display

⑤ "MHz" – appears when the frequency is displayed

⑥ Transmitter low battery icon
(LOW BAT warning)

⑦ Lock mode icon
(lock mode is activated)

⑧ 8-step level display for received RF signal "RF"

⑨ 8-step level display for received audio signal "AF", with "PEAK" warning

⑩ "PILOT" display
(pilot tone evaluation is activated)

⑪ Diversity display
(antenna I or antenna II active)

⑫ "MUTE" display
(audio output is muted)

EK 100 G2 bodypack receiver



Operating controls

1. Audio output (AF OUT), 3.5 mm jack socket (unbalanced)
2. Antenna
3. Red LED for operation and battery status indication (ON/LOW BAT)
4. Green LED for RF signal indication (RF)
5. SET button
6. ▼/▲ rocker button (DOWN/UP)
7. Battery compartment
8. Battery compartment cover
9. Unlocking button
10. ON/OFF button (serves as the ESC (cancel) key in the operating menu)
11. LC display

LC display panel

① Alphanumeric display
② "B.CH" – appears when the channel bank and the channel number are displayed
③ "MHz" – appears when the frequency is displayed
④ 4-step battery status display
⑤ Lock mode icon (lock mode is activated)
⑥ "PILOT" display (pilot tone evaluation is activated)
⑦ "MUTE" display (audio output is muted)
⑧ 7-step level display for received audio signal "AF"
⑨ 7-step level display for received RF signal "RF"

SK 100 G2 bodypack transmitter



Operating controls

1. Microphone/line input (MIC/LINE), 3.5 mm jack socket
2. Antenna
3. Red LED for operation and battery status indication (ON/LOW BAT)
4. Yellow LED for audio peak (AF PEAK)
5. SET button
6. ▼/▲ rocker button (DOWN/UP)
7. Battery compartment
8. Battery compartment cover
9. Unlocking button
10. ON/OFF button (serves as the ESC (cancel) key in the operating menu)
11. LC display
12. MUTE switch

LC display panel

① Alphanumeric display
② "B.CH" – appears when the channel bank and the channel number are displayed
③ "MHz" – appears when the frequency is displayed
④ 4-step battery status display
⑤ Lock mode icon (lock mode is activated)
⑥ "PILOT" display (pilot tone transmission is activated)
⑦ "MUTE" display (audio input is muted)
⑧ 7-step level display for audio signal "AF"

SKP 100 G2 plug-on transmitter



Operating controls

1. Microphone input, XLR-3F socket (unbalanced)
2. Mechanical locking ring of XLR-3 socket
3. LC display
4. SET button
5. ▼ button (DOWN)
6. ▲ button (UP)
7. Red LED for operation and battery status indication (ON/LOW BAT)
8. ON/OFF button (serves as the ESC (cancel) key in the operating menu)
9. Battery compartment cover
10. MUTE switch

LC display panel

1. Alphanumeric display
2. "B.CH" – appears when the channel bank and the channel number are displayed
3. "MHz" – appears when the frequency is displayed
4. 4-step battery status display
5. Lock mode icon (lock mode is activated)
6. "PILOT" display (pilot tone transmission is activated)
7. "MUTE" display (audio input is muted)
8. 7-step level display for audio signal "AF"

SKM 100 G2 radiomicrophone



Operating controls

1. Sound inlet basket
2. Color-coded identification ring for microphone heads

   green: MD 835 microphone head
   blue: MD 845 microphone head
   red: ME 865 microphone head
3. Body of radiomicrophone
4. Battery compartment (not visible from outside)
5. Display section
6. LC display
7. Turnable protective cap for operating controls (shown removed)

   The following operating controls become accessible in turn by turning the protective cap:

   8. SET button
   9. ▼ button (DOWN)
   10. ▲ button (UP)
   11. Red LED for operation and battery status indication (ON/LOW BAT)
   12. ON/OFF button (serves as the ESC (cancel) key in the operating menu)
   13. MUTE switch

LC display panel

① Alphanumeric display

② "B.CH" – appears when the channel bank and the channel number are displayed

③ "MHz" – appears when the frequency is displayed

④ 4-step battery status display

⑤ Lock mode icon (lock mode is activated)

⑥ "PILOT" display (pilot tone transmission is activated)

⑦ "MUTE" display (audio input is muted)

⑧ 7-step level display for audio signal "AF"

Indications and displays on the receivers

Operation and battery status indication (EK 100 G2 only)



The red LED (LOW BAT/ON) 3 provides information on the current operating state of the EK 100 G2:

Red LED lit up:	The receiver is switched on and the capacity of the batteries/accupack BA 2015 is sufficient.
Red LED flashing:	The batteries are/the accupack BA 2015 is going flat (LOW BAT)!

In addition, the 4-step battery status display ④ on the display panel provides information on the remaining battery/accupack BA 2015 capacity:

3 segments:	capacity approx. 100 %
2 segments:	capacity approx. 70 %
1 segment:	capacity approx. 30 %
Battery icon flashing:	LOW BAT

Transmitter battery status indication (EM 100 G2 only)



When the capacity of the transmitter batteries/accupack is so low that the batteries/accupack must soon be replaced (LOW BAT), the transmitter transmits information on its remaining battery/accupack capacity to the EM 100 G2 receiver and the transmitter low battery icon ⑥ starts flashing on the receiver display panel.

"MUTE" display



EM 100 G2



EK 100 G2

The "MUTE" display ⑫ or ⑦ appears when

- the RF signal of the received transmitter is too weak,
- the received transmitter has been muted (with the pilot tone transmission or evaluation activated).

RF signal indication (EK 100 G2 only)



The green LED (RF) 4 at the front of the EK 100 G2 lights up when an RF signal is being received.

Modulation display of the receiving transmitter



EM 100 G2



EK 100 G2

The level display for audio signal "AF" shows the modulation of the transmitter.

When the transmitter's audio input level is excessively high (AF peak), the receiver's level display for audio signal "AF" shows full deflection.

"PILOT" display



EM 100 G2



EK 100 G2

The "PILOT" display ⑩ or ⑥ lights up when the pilot tone evaluation is activated (see: „Activating/deactivating the pilot tone transmission or pilot tone evaluation" on page 35).

Diversity display (EM 100 G2 only)



The EM 100 G2 receiver operates on the true diversity principle (see: „Diversity reception" on page 41).

The diversity display ⑪ indicates whether diversity section I (i.e. antenna 1) or diversity section II (i.e. antenna 2) is active.

Display backlighting (EK 100 G2 only)

After pressing a button, the display remains backlit for approx. 15 seconds.

Indications and displays on the transmitters

Operation and battery status indication



The red LED (LOW BAT/ON) provides information on the current operating state of the transmitter:

Red LED lit up:	The transmitter is switched on and the capacity of the batteries/accupack BA 2015 is sufficient.
Red LED flashing:	The batteries are/the accupack BA 2015 is going flat (LOW BAT)!

In addition, the 4-step battery status display ④ on the display panel provides information on the remaining battery/accupack BA 2015 capacity:

3 segments:	capacity approx. 100 %
2 segments:	capacity approx. 70 %
1 segment:	capacity approx. 30 %
Battery icon flashing:	LOW BAT

"MUTE" display



The "MUTE" display ⑦ appears on the display panel when the transmitter is muted (see: „Muting the transmitters" on page 23).

Modulation display



The level display for audio signal (AF) shows the modulation of the transmitter.

AF peak indication (SK 100 G2 only)



The yellow LED (AF PEAK) ❹ at the front of the SK 100 G2 lights up when the audio input level is excessively high (AF peak) and overmodulates the transmitter. At the same time, the 7-step level display for audio signal "AF" shows full deflection for the duration of the overmodulation.

"PILOT" display



The "PILOT" display ⑥ lights up when the transmitter display panel if the pilot tone transmission is activated (see: „Activating/deactivating the pilot tone transmission or pilot tone evaluation" on page 35).

Display backlighting (SK 100 G2 only)

After pressing a button, the display remains backlit for approx. 15 seconds.

Preparing the components for use

EM 100 G2 rack-mount receiver

Mounting the receiver feet

To ensure that the receiver cannot slip on the surface on which it is placed, four self-adhesive soft rubber feet are supplied.



- Ensure that the base of the receiver is clean before mounting the rubber feet.
- Fix the rubber feet to the base of the receiver by peeling of the safety paper and fitting them as shown in the digram on the left.

Attention!

Some furniture surfaces have been treated with varnish, polish or synthetics which might cause stains when they come into contact with other synthetics. Despite a thorough testing of the synthetics used by us, we cannot rule out the possibility of staining.

Connecting the antennas



The supplied telescopic antennas can be mounted quickly and easily to the rear of the receiver and are suitable for all applications where – good reception conditions provided – a wireless transmission system is to be used without a large amount of installation work.

- Connect the telescopic antennas to the BNC sockets 11 and 13 at the rear of the receiver.
- Pull the telescopic antennas 14 out and align the upwards in a V-shape.

Use remote antennas when the receiver position is not the best antenna position for optimum reception.

Connecting the mains unit



The EM 100 G2 is powered via a mains unit.

- Pass the cable through the cable grip 6.
- Insert the DC connector on the mains cable into the DC socket 7.

Connecting the amplifier/mixing console

The EM 100 G2's audio outputs are available as an XLR-3M socket 8 and a ¼" (6.3 mm) jack socket 9, allowing you to simultaneously connect two units (e.g. amplifier, mixing console). The adjusted audio output level is common for both sockets.



- Connect the amplifier/mixing console to the XLR-3M socket 8 or the ¼" (6.3 mm) jack socket 9.

  For detailed information on balanced and unbalanced connection, please refer to the section "Connector assignment" auf Seite 43.

- Via the operating menu, adapt the level of the audio output (AF OUT) to the input of the amplifier or mixing console (see: „Adjusting the audio output level (receivers only)" on page 33).

Service interface



The service interface 10 is only required for servicing purposes.

19" rack adapter and antenna mount (accessories)



For mounting one or two receivers into a 19" rack, you require the GA 2 rack adapter. The GA 2 rack adapter consists of:

- 2 rack mount "ears" 15
- 1 connecting bar 16
- 1 connecting plate 17
- 2 covering plugs 18 for antenna holes
- 12 recessed head screws M 3x6
- 2 recessed head screws M 6x10



When mounting only one receiver into a rack, you can use the AM 2 antenna mount (available as an accessory) to mount the transmitter's antenna connection to the front of the GA 2 rack adapter. The AM 2 antenna mount consists of :

- 2 BNC extension cables (screw-in BNC socket 19 to BNC connector 20)
- 2 plains washers
- 2 nuts



To mount two EM 100 G2 into a rack:

- Place the two receivers side by side onto a flat surface, their bottom sides facing upwards.
- Align the connecting plate 17 over the holes in the bottom sides of the receivers.
- Secure the connecting plate 17 to the receivers using eight of the supplied recessed head screws (M 3x6).
- Hook the two rack mount "ears" 15 to the front panels of the receivers.
- Secure the rack mount "ears" to the receivers using two of the supplied recessed head screws (M 3x6) respectively.
- Slide the receivers into a 19" rack.
- Screw the rack mount "ears" tight.



When mounting only one receiver into a rack, use the connecting bar 16 instead of the second receiver.

- Hook the two rack mount "ears" 15 to the front panel of the receiver.
- Secure the rack mount "ears" to the receiver using two of the supplied recessed head screws (M 3x6) respectively.
- Secure the connecting bar 16 to one of the rack mount "ears" 15 using two of the supplied recessed head screws (M 6x10).
- If you are not front mounting the antennas, insert the two covering plugs 18 into the antenna holes of the connecting bar.
- Slide the receiver into a 19" rack.
- Screw the rack mount "ears" tight.



To mount the receiver's antenna connection to the front of the GA 2 rack adapter using the AM 2 antenna mount:

- Screw the two BNC sockets 19 of the BNC extension cables to the connecting bar 16 using the supplied plain washers and nuts.
- Connect the two BNC connectors 20 to the BNC sockets 11 and 13 at the rear of the receiver.
- Slide the receiver into a 19" rack.
- Screw the rack mount "ears" tight.
- Connect the two telescopic antennas 14 to the two BNC sockets 19.
- Pull the telescopic antennas out and align them upwards in a V-shape.

Inserting and replacing the batteries



For powering the EK 100 G2 bodypack receiver, you can either use two 1.5 V AA size batteries or the rechargeable Sennheiser BA 2015 accupack.

- Press the two unlocking buttons 9 and open the battery compartment cover 8.
- Insert the two batteries or the BA 2015 accupack as shown in the diagram on the left. Please observe correct polarity when inserting the batteries/ accupack.
- Close the battery compartment. The battery compartment cover 8 locks into place and clicks.

Note:

For accupack operation of the receiver, only use the BA 2015 accupack In order to ensure optimum operational reliability. For charging the accupack, only use the L 2015 charger. Both the accupack and the charger are available as accessories.
The accupack is fitted with an integrated sensor which is – via a third contact – monitored by the electronics of the receiver and the charger. The sensor is necessary for the following control purposes:

- The taking into account of the different voltage characteristics of primary cells (batteries) and accupacks. The battery status indications on the displays, the transmission of transmitter battery status information to the rack-mount receivers and the switch-off thresholds at the end of the operating time are corrected correspondingly. Due to the missing sensor, individual rechargeable battery cells will not be identified as accupacks.
- The monitoring of the accupack temperature during charging in the L 2015 charger.
- The prevention of improper charging of inserted primary cells (batteries). Due to the missing sensor, individual rechargeable battery cells will also not be charged in the L 2015 charger.

Connecting units to the audio output



You can connect a PA system or a recording unit (e.g. video camera) to the EK 100 G2 bodypack receiver.

- Connect one of the supplied line output cables to the recording unit.
- Connect the 3.5 mm jack plug to the audio output (AF OUT) 1.
- Lock the 3.5 mm jack plug by screwing down the coupling ring.
- Via the operating menu, adapt the level of the audio output (AF OUT) to the input sensitivity of the connected unit (see: „Adjusting the audio output level (receivers only)“ on page 33).



Mounting the bodypack receiver to a camera

Use the supplied camera kit to mount the receiver to the camera's flash mount.

The camera kit consits of:

- 1 perforated plate 12
- 1 flash mount adapter 13
- 2 square nuts 14

▶ Determine where on the perforated plate the flash mount adapter 13 will need to be fastened so that the receiver can best be attached to the camera.

▶ At this position, place a square nut 14 under the perforated plate 12.

▶ Fasten the flash mount adapter to the perforated plate using the square nut.

▶ Remove the belt clip.

▶ Place the perforated plate 12 onto the rear of the receiver.

▶ Reinsert the belt clip.

SK 100 G2 bodypack transmitter



Inserting and replacing the batteries

For powering the SK 100 G2 bodypack transmitter, you can either use two 1.5 V AA size batteries or the rechargeable Sennheiser BA 2015 accupack.

▶ Press the two unlocking buttons 9 and open the battery compartment cover 8.

▶ Insert the two batteries or the BA 2015 accupack as shown in the diagram on the left. Please observe correct polarity when inserting the batteries/ accupack.

▶ Close the battery compartment. The battery compartment cover 8 locks into place with an audible click.

Note:

For important informations on charging the accupack see: „Inserting and replacing the batteries" on page 17.



Connecting the microphone/line cable

The microphone/line input is designed for the connection of both condenser microphones and instruments (e.g. guitars). DC powering of the condenser microphones is via the microphone/line input.

▶ Connect the 3.5 mm jack plug 13 from the microphone/line cable to the 3.5 mm jack socket (MIC/LINE) 1.

▶ Lock the 3.5 mm jack plug by screwing down the coupling ring 14.

▶ Via the operating menu, adjust the sensitivity of the microphone/line input (MIC/LINE) (see: „Adjusting the sensitivity (transmitters only)" on page 32).



Attaching the microphones

- Use the microphone clips (15) to attach the ME 2 and ME 4 clip-on microphones to clothing (e.g. tie, lapel).
- Adjust the ME 3 headmic so that a comfortable and secure fit is ensured.



Positioning the microphones

The ME 3 and ME 4 microphones are directional microphones, i.e. their sound inlet should always be directed towards the sound source (e.g. mouth).

The ME 2 with omni-directional pick-up pattern picks up sound equally from all directions. It is the best choice if movements of the speaker's head have to be compensated for. However, it should be attached as close as possible to the sound source.

Adjust the sensitivity correctly for all microphones/usages (see: „Adjusting the sensitivity (transmitters only)" on page 32).

SKP 100 G2 plug-on transmitter



Inserting and replacing the batteries

For powering the SKP 100 G2 plug-on transmitter, you can either use two 1.5 V AA size batteries or the rechargeable Sennheiser BA 2015 accupack.

- Slide the battery compartment cover (9) in the direction of the embossed arrow and opern the cover.
- Insert the two batteries or the BA 2015 accupack as shown in the diagram on the left. Please observe correct polarity when inserting the batteries/accupack.
- Close the battery compartment. The battery compartment cover (8) locks into place with an audible click.

Note:

For accupack operation of the transmitter, only use the BA 2015 accupack In order to ensure optimum operational reliability. For charging the accupack, only use the L 2015 charger. Both the accupack and the charger are available as accessories.
The accupack is fitted with an integrated sensor which is – via a third contact – monitored by the electronics of the transmitter and the charger. The sensor is necessary for the following control purposes:

- The taking into account of the different voltage characteristics of primary cells (batteries) and accupacks. The battery status indications on the displays, the transmission of transmitter battery status information to the rack-mount receivers and the switch-off thresholds at the end of the operating time are corrected correspondingly. Due to the missing sensor, individual rechargeable battery cells will not be identified as accupacks.
- The monitoring of the accupack temperature during charging in the L 2015 charger.



Plugging the plug-on transmitter onto a microphone

- Plug the transmitter's XLR-3F socket 1 onto the microphone's XLR-3M socket.
- Tighten the locking ring 2 as shown in the diagram on the left.

Note:

The transmitter uses the microphone body as an antenna – therefore only microphones with a metal casing should be used for best signal transmission.

SKM 100 G2 radiomicrophone



Inserting and replacing the batteries

For powering the SKM 100 G2 radiomicrophone, you can either use two 1.5 V AA size batteries or the rechargeable Sennheiser BA 2015 accupack.

- Unscrew the display section 5 from the radiomicrophone's body 3 by turning it counterclockwise.
- Slide back the display section 5 as far as it will go.
- Open the battery compartment cover 14.
- Insert the two batteries or the BA 2015 accupack as shown in the diagram on the left. Please observe correct polarity when inserting the batteries/ accupack.
- Close the battery compartment cover 14.
- Push the battery compartment into the radiomicrophone's body.
- Screw the display section tight.

Note:

For important informations on charging the accupack see: „Inserting and replacing the batteries" on page 19.



Changing the microphone head

- First remove the batteries/accupack as described above and leave the radiomicrophone open.
- Unscrew the sound inlet basket.
- Loosen the screw and put it to one side.
- Gently ease the capsule out of the contacts and then pull it out of the housing as shown. Do not touch the contacts and the diaphragm!
- Insert the new capsule.
- Secure the capsule by tightening the screw.

Note:

The screw mechanically secures the microphone capsule. If the screw is missing, malfunctions may occur during tough use.

- Put on the sound inlet basket and identification ring supplied with the new microphone head (NB: do NOT use the old basket, as the different heads use slightly differing internal foam) and screw it tight.
- Insert the batteries/accupack.
- Close the radiomicrophone and put it into operation.

Note:

Microphone capsule, sound inlet basket and foam insert form an acoustic unit and must therefore always be exchanged all together. Each microphone head comes with a color-coded identification ring to distinguish different microphone heads from each other (green = MD 835, blue = MD 845, red = ME 865).

Using the components

Switching the components on/off

The ew 100 G2 transmitters and receivers can only be switched off when the standard display is shown on the display panel. Within the operating menu, the ON/OFF button or the POWER button (EM 100 G2 only) serves as the ESC (cancel) key, i.e you cancel your entry and return to the standard display.

> **Note:**
>
> Remove the batteries or the accupack when the units will not be used for extended periods of time.

Switching the rack-mount receiver on/off



- Press the POWER button 5 to switch the receiver on.
- To switch the receiver off, press the POWER button until "OFF" appears on the display.

Switching the bodypack receiver/transmitter on/off



- Press the two unlocking buttons 9 and open the battery compartment cover 8.
- Press the ON/OFF button 10 to switch the bodypack receiver/transmitter on. The red LED 3 lights up.
- To switch the bodypack receiver/transmitter off, press the ON/OFF button 10 until "OFF" appears on the display. The red LED 3 goes off.
- Close the battery compartment. The battery compartment cover 8 locks into place with an audible click.

Switching the plug-on transmitter on/off



- Press the ON/OFF button 8 to switch the plug-on transmitter on. The red LED 7 lights up.
- To switch the plug-on transmitter off, press the ON/OFF button 8 until "OFF" appears on the display. The red LED 7 goes off.



Switching the radiomicrophone on/off

- Turn the protective cap 7 at the bottom of the radiomicrophone so that the ON/OFF button 12 becomes accessible.
- Press the ON/OFF button to switch the radiomicrophone on. The red LED 11 lights up.
- To switch the radiomicrophone off, press the ON/OFF button 12 until "OFF" appears on the display. The red LED 11 goes off.

Muting the transmitters



All transmitters have a MUTE switch that noiselessly mutes the transmitter's audio signal without switching the transmitter off.

Muting the SK 100 G2 and SKP 100 G2 transmitters

- Set the MUTE switch to the position 'MUTE'. The "MUTE" display appears on the transmitter display panel. Provided that the pilot tone function is activated on both the transmitter and the receiver, the "MUTE" display also appears on the receiver display panel.
- Set the MUTE switch back to the original position to retransmit the audio signal.



Muting the SKM 100 G2 radiomicrophone

- Turn the protective cap 7 at the bottom of the radiomicrophone so that the MUTE switch 13 becomes accessible.
- Set the MUTE switch to the position 'MUTE'. The "MUTE" display appears on the transmitter display panel. Provided that the pilot tone function is activated on both the transmitter and the receiver, the "MUTE" display also appears on the receiver display panel.
- Set the MUTE switch back to the original position to retransmit the audio signal.

Activating/deactivating the lock mode

All transmitters and receivers have a lock mode that can be activated or deactivated via the operating menu (see: „Activating/deactivating the lock mode" on page 35). The lock mode prevents that the transmitter or receiver is accidentally programmed or switched off during operation.

Attaching the components to clothing

Attaching the bodypack receiver/transmitter to clothing



The bodypack receiver/transmitter is attached to clothing (e.g. belt, waistband) with the supplied belt clip.

The clip is detachable so that you can also attach the bodypack receiver/transmitter with the antenna pointing downwards. To do so, withdraw the clip from its fixing points and attach it the other way round.

The BPP 1 bodypack pouch (available as an accessory) helps to protect the bodypack receiver/transmitter against moisture.

The operating menu

A special feature of the Sennheiser ew 100 G2 series is the similar, intuitive operation. As a result, the units are easy to operate and adjustments to the settings can be made quickly and "without looking" – even in stressful situations, for example on stage or during a live show or presentation.

The buttons

Buttons	Mode	To ...
ON/OFF or POWER (EM 100 G2 only)	Standard display	turn the transmitter or receiver on and off
	Operating menu	cancel the entry and return to the standard display
	Setting mode	cancel the entry and return to the standard display
SET	Standard display	get into the operating menu
	Operating menu	get into the setting mode of the selected menu
	Setting mode	store the settings and return to the previous menu level
▲/▼	Standard display	without function
	Operating menu	change to the previous menu (▲) or change to the next menu (▼)
	Setting mode	adjust the setting of the selected menu: option (▲/▼)

Overview of menus

Display	Receivers	Transmitters
BANK	Switching between channel banks	Switching between channel banks
CHAN	Switching between the channels in a channel bank	Switching between the channels in a channel bank
TUNE	Setting a receiving frequency for the channel bank "U" (user bank)	Setting a transmission frequency for the channel bank "U" (user bank)
SCAN	Scanning the selected channel bank for free channels	—
SENSIT	—	Adjusting the sensitivity (AF)
AF OUT	Adjusting the audio output level	—
SQELCH	Adjusting the squelch threshold	—
DISPLY	Selecting the standard display	Selecting the standard display
NAME	Entering a name	Entering a name
RESET	Loading the factory-preset default settings	Loading the factory-preset default settings
PILOT	Activating/deactivating the pilot tone evaluation	Activating/deactivating the pilot tone transmission
LOCK	Activating/deactivating the lock mode	Activating/deactivating the lock mode
EXIT	Exiting the operating menu and returning to the standard display	Exiting the operating menu and returning to the standard display

Working with the operating menu



EM 100 G2



EK 100 G2



Trans-
mitters

By way of example of the "TUNE" menu, this section describes how to use the operating menu.

After switching the unit on, the standard display is shown on the display panel.

Getting into the operating menu

▶ Press the SET button to get from the standard display into the operating menu. The last menu selected flashes on the display.

Selecting a menu

▶ Press the ▲/▼ buttons to select a menu.

▶ Press the SET button to get into the setting mode of the selected menu. The current setting that can be adjusted flashes on the display.

Adjusting a setting

▶ Press the ▲/▼ buttons to adjust the setting. By briefly pressing the ▲/▼ buttons, the display jumps either forwards or backwards to the next setting. In the "CHAN", "TUNE" and "NAME" menu, the ▲/▼ buttons feature a "fast search" function. If you hold down a button, the display cycles continuously. The "fast search" function allows you to get fast and easily to your desired setting. The new setting flashes on the display until it is stored.

Storing a setting

▶ Press the SET button to store the setting. "STORED" appears on the display, indicating that the setting has been stored. The display then returns to the previous menu level.

With most menus, new settings become effective immediately without having to be stored. An exception are the "BANK", "CHAN", "TUNE" and "RESET" menus of the transmitters and the "RESET" menu of the receivers. With these menus, new settings only become effective after they have been stored ("STORED" appears on the display, indicating that the setting has been stored).

Exiting the operating menu

▶ Select the "EXIT" menu to exit the operating menu and to return to the standard display.

When you have entered the operating menu, the ON/OFF button or the POWER button (EM 100 G2 receiver only) serves as the ESC (cancel) key, i.e. by briefly pressing the ON/OFF or POWER button, you cancel your entry and return to the standard display.

Operating menu of the receivers



EXIT

SET

BANK
Changing the channel bank
SET → BANK 1
Current channel bank
▲/▼ → BANK U
▲/▼: 1...8, U (User Bank)
SET: Stores the setting
STORED

CHAN
Changing the channel
SET → 1.01 B.CH 790.025 MHz
Current channel (display depends on "DISPLY" setting)
▲/▼ → 1.04 B.CH 790.100 MHz
▲/▼: Channel 01...04
SET: Stores the setting
STORED

TUNE
Setting the frequency for channel bank "U"
SET → 790.025 MHz
Current frequency on the selected channel
▲/▼ → 791.125 MHz
▲/▼: Receiving frequency in steps of 25 kHz
SET: Stores the setting
STORED

SCAN
Scanning the selected channel bank for free channels
SET → START
▲/▼ → CLEAR
▲/▼: CLEAR, START
Start scan = START
SET: Scans the selected channel bank for free channels
04 CH FREE
SET
STORED
Delete result = CLEAR
SET: Releases locked channels

AF OUT
Setting the audio output level
SET → LEV +18
Current audio output level
▲/▼ → LEV -24
▲/▼: (in steps of 6 dB):
EM 100 G2:+18...0...-24 dB
EK 100 G2: +12...0...-30 dB
SET: Stores the setting
STORED

SQELCH
Setting the squelch threshold
SET → SQ LO
Current squelch threshold
▲/▼ → SQ HI
▲/▼: LO, MID, HI
SET: Stores the setting
STORED

DISPLY


SQELCH
DISPLY
Switching between the standard displays
SET
FREQ
Current standard display
NAME
▲/▼: Select standard display
EM 100 G2: FREQ, NAME
EK 100 G2: FREQ, NAME, CHAN
SET: Stores the setting
STORED
NAME
Assigning the receiver a name
SET
VOCAL
Current receiver name
GUCAL
▲/▼: Enter a name (6 characters)
Letters w/o pronounciation marks, numbers from 0...9, special characters, spaces
SET: 5 x next character, then store
STORED
RESET
Loading the factory-preset default settings
SET
RST. NO
Security check
RST. OK
▲/▼: OK, NO
"reset" = OK:
SET: Receiver loads factory-preset default settings (only pilot tone setting is kept), receiver is restarted, standard display appears
"reset" = NO
SET: Reset is cancelled
PILOT
Activating/deactivating the pilot tone evaluation
SET
PLT. ON
Pilot tone evaluation activated or deactivated
PLT. OFF
▲/▼: ON, OFF
SET: Stores the setting
STORED
LOCK
Activating the lock mode
SET
LOC.OFF
Lock mode activated or deactivated
LOC.ON
▲/▼: ON, OFF
Lock mode = ON:
SET: Stores the setting (STORED), returns to standard display
Lock mode = OFF:
SET: Stores the setting
STORED
EXIT
Exiting the operating menu
SET
B.CH
MHz
RF
AF
PILOT
BANK

Operating menu of the transmitters




DISPLY
NAME
Assigning the transmitter a name
SET
VOCAL
Current transmitter name
GUCAL
▲/▼: Transmitter name (6 characters)
Letters w/o pronounciation marks, numbers from 0...9, special characters, spaces
SET: 5 x next character, then store
STORED
RESET
Loading the factory-preset default settings
SET
RST. NO
Security check
RST. OK
▲/▼: OK, NO
"reset" = OK:
SET: Transmitter loads factory-preset default settings (only pilot tone setting is kept), transmitter is restarted, standard display appears
"reset" = NO
SET: Reset is cancelled
PILOT
Activating/deactivating the pilot tone transmission
SET
PLT. ON
Pilot tone transmission activated or deactivated
PLT. OFF
▲/▼: ON, OFF
SET: Stores the setting
STORED
LOCK
Activating the lock mode
SET
LOC.OFF
Lock mode activated or deactivated
LOC.ON
▲/▼: ON, OFF
Lock mode = ON:
SET: Stores the setting (STORED), returns to standard display
STORED
Lock mode = OFF:
SET: Stores the setting
EXIT
Exiting the operating menu
SET
MHz
AF
PILOT
BANK

Adjustment tips for the operating menu

Switching between channel banks

BANK

Via the "BANK" menu, you can switch between the nine channel banks of the transmitters and receivers. The channel banks "1" to "8" have four switchable channels that are factory-preset to a transmission/receiving frequency (see: „The channel bank system" on page 4). The channel bank "U" (user bank) has four switchable channels to store your selection out of 1440 transmission/receiving frequencies that are freely selectable within the preset frequency range.

When switching from one channel bank to another, the channel with the lowest channel number is automatically displayed. If, during the last scan of this channel bank, an interfering frequency was detected on the channel with the lowest channel number (see: „Scanning the channel banks for free channels (receivers only)" on page 31), the receiver display panel automatically displays the next free channel.

Switching between the channels in a channel bank

CHAN

Via the "CHAN" menu, you can switch between the four channels in a channel bank.

Always set the transmitter and the receiver of a transmission link to the same channel. After scanning a channel bank (see: „Scanning the channel banks for free channels (receivers only)" on page 31), only the free channels are displayed. Set the transmitter to one of the free channels.

Selecting the frequencies to be stored in the channel bank "U"

TUNE

Via the "TUNE" menu, you can select the frequencies to be stored in the channel bank "U" (user bank).

When you have selected one of the channel banks "1" to "8" and then select the "TUNE" menu, the transmitter or receiver automatically switches to channel 01 of the channel bank "U". In this case, "U.01" briefly appears on the display.

- Use the ▲/▼ buttons to select the desired transmission or receiving frequency. Transmission and receiving frequencies are tunable in 25-kHz steps within a switching bandwidth of 36 MHz max. For intermodulation-free frequencies, please refer to the enclosed frequency table.

Scanning the channel banks for free channels (receivers only)

SCAN

Before putting one or several transmission links into operation, you should scan the selected channel bank for free channels In order to ensure intermodulation-free operation of your system.

Starting the scan and storing the scan result

- Before starting the scan, switch all transmitters of your system off, since channels used by switched-on transmitters will not be displayed as "free channels".
- Select the "SCAN" menu.
- Select "START" and confirm your selection by pressing the SET button. After the scan is completed, the number of free channels is displayed. Pressing the SET button once more will store the scan result and lock all channels that are used or subject to interference.

Releasing locked channels

- Select the "SCAN" menu.
- Select "CLEAR" and confirm your selection by pressing the SET button. All channels in this channel bank can now be selected again.

Multi-channel operation

For multi-channel operation, only use the free channels in a channel bank.

Before putting the transmission links into operation, we recommend performing an auto scan.

- Select a channel bank on a receiver.
- Scan this channel bank for free channels. If not enough free channels are available in the selected channel bank, repeat the scan with another channel bank.
- Apply the scan result to all other transmitters and receivers.

Adjusting the sensitivity (transmitters only)

SENSIT





EM 100 G2 EM 100 G2



EK 100 G2

Via the "SENSIT" menu, you can adjust the modulation level of the transmitters. This changes the transmitter's input sensitivity.

The input sensitivity is adjusted too high when close talking distances, speakers with loud voices or loud music passages cause overmodulation in the transmission link. In this case, the SK 100 G2's yellow LED (AF PEAK) 4 will light up and the receiver's level display for audio signal (AF) will show full deflection (see: „Modulation display of the receiving transmitter" on page 12).

If, on the other hand, the sensitivity is adjusted too low, the transmission link will be undermodulated, which would result in a signal with high background noise.

The sensitivity is correctly adjusted when the level display for audio signal "AF" shows full deflection only during the loudest passages.

Note:

For monitoring the adjusted sensitivity, the transmitter's level display for audio signal (AF) always indicates the audio level – even if the transmitter is muted.

The following figures are a guide to the best settings:

- Loud music/vocals: –30 to –20 dB
- Presentations: –20 to –10 dB
- Interviews: –10 to 0 dB
- Musical instruments:
  - electric guitars with single coil pickups: –10 to 0 dB
  - electric guitars with humbucker pickups: –20 to –10 dB
  - guitars with active electronics (active pickups, active EQs, piezo pickups): –30 to –20 dB

Special feature of the SKP 100 G2 plug-on transmitter:

In order to be able to use highly sensitive directional condenser microphones with separate powering, the SKP 100 G2 plug-on transmitter offers a sensitivity range extended by 20 dB. With the transmitter plugged onto a directional condenser microphone, the following figures are a guide to the best settings:

- Loud music/vocals: –50 to –40 dB
- Presentations: –40 to –30 dB
- Interviews: –30 to –20 dB

Adjusting the audio output level (receivers only)

AF OUT

Via the "AF OUT" menu, you can adjust the audio output level of the receivers. The level can be adjusted in eight steps. Adapt the level of the audio output (AF OUT) to the input of the connected unit. The following figures are a guide to the best settings:

	EM 100 G2	EK 100 G2
• Line level input:	0 bis +18 dB	0 bis +12 dB
• Microphone level input:	–24 bis –6 dB	–30 bis –6 dB

Adjusting the squelch threshold (receivers only)

SQELCH

The receiver is equipped with a squelch that can be adjusted via the "SQELCH" menu. The squelch eliminates annoying noise when the transmitter is switched off. It also suppresses sudden noise when there is no longer sufficient transmitter power received by the receiver.

Note:

Before adjusting the squelch threshold to a different setting, set the volume on a connected amplifier to the minimum.

There are three possible squelch settings:

- LO = low
- MID = middle
- HI = high

Selecting the setting "LO" reduces the squelch threshold, selecting the setting "HI" increases the squelch threshold. Adjust the squelch threshold – with the transmitter switched off – to the lowest possible setting that suppresses hissing noise.

IMPORTANT! Notes:

If the squelch threshold is adjusted too high, the transmission range will be reduced. Therefore, always adjust the squelch threshold to the lowest possible setting. The squelch threshold is factory-preset to "LO".

When in the setting mode of the "SQELCH" menu, pressing the ▼ button (DOWN) for more than three seconds will switch the squelch off. "SQ.OFF" appears on the display. If no RF signal is being received, hissing noise will occur. This setting is for test purposes only.

Selecting the standard display

DISPLY

Via the "DISPLY" menu, you can select the standard display:

selectable Standard display	Contents of standard display		
	EM 100 G2	EK 100 G2	SK 100 G2, SKM 100 G2, SKP 100 G2
„FREQ"			
„NAME"			
„CHAN"	—		

Entering a name

NAME

Via the "NAME" menu, you can enter a freely selectable name for each transmitter and receiver. You can, for example, enter the name of the performer for whom the adjustments have been made.

The name can be displayed on the standard display and can consist of up to six characters such as:

- letters (without pronounciation marks),
- numbers from 0 to 9,
- special characters e.g. () - . _ and spaces.

To enter a name, proceed as follows:

▶ Press the SET button to get into the setting mode of the "NAME" menu. The first segment starts flashing on the display.

▶ With the ▲/▼ buttons you can now select a character. By briefly pressing a button, the display jumps either forwards or backwards to the next character. If you hold down a button, the display starts cycling continuously.

▶ Press the SET button to change to the next segment and select the next character.

▶ Have you entered the name completely? Press the SET button to store your setting and to return to the previous menu level.

Loading the factory-preset default settings

RESET

Via the "RESET" menu, you can load the factory-preset default settings. Only the selected setting for the pilot tone remains unchanged. After the reset, the unit is restarted and the standard display is shown on the display panel.

Activating/deactivating the pilot tone transmission or pilot tone evaluation

PILOT

Via the "PILOT" menu, you can activate or deactivate the pilot tone transmission of the transmitters and the pilot tone evaluation of the receivers.

The pilot tone supports the squelch function (SQELCH) and protects against interference due to RF signals from other units. The transmitter adds an inaudible signal, known as the pilot tone, to the transmitted signal. The receiver detects and evaluates the pilot tone, and is thus able to identify the signal of the matching transmitter and mute all others.

Transmitters of the ew 100 series (first generation) do not transmit a pilot tone and receivers of the ew 100 series (first generation) cannot evaluate the pilot tone. Nevertheless, you can combine units of the ew 100 series (first generation) with units of the ew 100 G2 series (second generation).

However, when combining units, please observe the following:

- With an ew 100 G2 transmitter and an ew 100 G2 receiver:
  Activate the pilot tone function with both transmitter and receiver.
- With an ew 100 transmitter and an ew 100 G2 receiver or vice versa:
  Deactivate the pilot tone function with the ew 100 G2 transmitter or receiver.

Activating/deactivating the lock mode

LOCK

Via the "LOCK" menu, you can activate or deactiveate the lock mode.



EM 100 G2



EK 100 G2



Trans-
mitters

The lock mode prevents that the transmitter or receiver is accidentally programmed or switched off during operation. The lock mode icon on the display indicates that the lock mode is activated.

To deactivate the lock mode, first press the SET button. Then press the ▲/▼ buttons to select "Lock Off".If you confirm your selection by pressing the SET button, "LOC.OFF" appears on the display and the buttons can be operated as usual.

Exiting the operating menu

Via the "EXIT" menu, you can exit the operating menu and return to the standard display.

If problems occur

Error checklist

Problem	Possible cause	Possible solution
No operation indication	Batteries are flat or accupack is flat	Replace the batteries or recharge the accupack
	No mains connection (EM 100 G2)	Check the connections of the mains unit
No RF signal	Transmitter and receiver are not on the same channel	Set transmitter and receiver to the same channel
	Transmitter is out of range	Check the squelch threshold setting (see: „Adjusting the squelch threshold (receivers only)“ on page 33) or reduce the distance between transmitter and receiving antenna
RF signal available, no audio signal, “MUTE” display appears on the display panel	Transmitter is muted (“MUTE”)	Deactivate the muting function
	Receiver’s squelch threshold is adjusted too high	see „Adjusting the squelch threshold (receivers only)“ on page 33
	Transmitter doesn’t transmit a pilot tone	see „Activating/deactivating the pilot tone transmission or pilot tone evaluation“ on page 35
Audio signal has a high level of background noise	Transmitter sensitivity is adjusted too low	see „Adjusting the sensitivity (transmitters only)“ on page 32
	Receiver’s AF output level is adjusted too low	see „Adjusting the audio output level (receivers only)“ on page 33
Audio signal is distorted	Transmitter sensitivity is adjusted too high	see „Adjusting the sensitivity (transmitters only)“ on page 32
	Receiver’s AF output level is adjusted too high	see „Adjusting the audio output level (receivers only)“ on page 33
No access to a certain channel	During scanning, an RF signal has been detected on this channel and the channel has been locked	see „Scanning the channel banks for free channels (receivers only)“ on page 31
	During scanning, a transmitter of your system operating on this channel has not been switched off	see „Multi-channel operation“ on page 32

If problems occur that are not listed in the above table or if the problems cannot be solved with the proposed solutions, please contact your local Sennheiser agent for assistance.

Recommendations and tips

... for the ME 2 and ME 4 clip-on microphones

- To reduce level variations to a minimum when the user turns his or her head away from the microphone, attach the microphone as centrally as possible.
- To protect the microphone against excessive sweat/moisture, avoid direct skin contact.
- Attach the microphone carefully and conduct the cable so that noise due to friction is avoided.
- Always use the ME 4 directional microphone with a windshield and direct the microphone towards the sound source (e.g. mouth).

... for the ME 3 headmic

- Always use the microphone with a popshield and position the microphone at the corner of the mouth.
- You can vary the bass reproduction by increasing/decreasing the talking distance to the microphone.
- Make sure that the sound inlet is directed towards the mouth. The sound inlet is marked with a little dot.

... for the SK 100 G2 bodypack transmitter

- Make sure that the antenna and the microphone cable do not cross.
- The antenna should hang freely and be at least 1 cm away from the body. The antenna must not be in direct contact with the skin.
- For best results, make sure that the transmitter sensitivity is correctly adjusted.

... for the SKM 100 G2 radiomicrophone

- Hold the SKM 100 G2 in the middle of the microphone body. Holding it close to the sound inlet basket will influence the microphone's pick-up pattern, holding it at the lower part of the body will reduce the transmitter's range.
- You can vary the bass reproduction by increasing/decreasing the talking distance to the microphone.
- For best results, make sure that the transmitter sensitivity is correctly adjusted.

... for the EK 100 G2 bodypack receiver

- The antenna should hang freely and be at least 1 cm away from the body. The antenna must not be in direct contact with the skin.

... for optimum reception

- Transmission range depends to a large extent on location and can vary from about 10 m to about 150 m. There should be a "free line of sight" between transmitting and receiving antennas.
- If, with the EM 100 G2 receiver, reception conditions are unfavourable, you should use two remote antennas which are connected via antenna cable.
- To avoid overmodulating the receiver, observe a minimum distance of 5 m between transmitting and receiving antennas.
- Observe a minimum distance of 50 cm between receiving antennas and metal objects (such as cross members or reinforced-concrete walls).

... for multi-channel operation

- For multi-channel operation, you can only use the channels in a channel bank. Each of the channel banks "1" to "8" accommodates four factory-preset frequencies which are intermodulation-free. For alternative frequency combinations, please refer to the enclosed frequency table. The freely selectable frequencies can be selected via the "TUNE" menu and can be stored in the channel bank "U".
- When using several transmitters simultaneously, interference can be avoided by maintaining a minimum distance of 20 cm between two transmitters.
- Use special accessories for multi-channel applications (see: „Accessories" on page 45).

Care and maintenance

Use a slightly damp cloth to clean the units from time to time.

Note:

Do not use any cleansing agents or solvents.



To clean the SKM 100 G2's sound inlet basket, proceed as follows:

- Unscrew the sound inlet basket (turn counterclockwise) and remove it.
- Remove the foam insert.
- Use a slightly damp cloth to clean the sound inlet basket from the inside and ouside.
- Reinsert the foam insert.
- Replace the sound inlet basket on the SKM 100 G2 and screw it tight (taking care not to loose the colored identification ring).

Additional information

HDX noise reduction



Progress you can hear:

The evolution wireless G2 series is equipped with HDX, the Sennheiser noise reduction system that reduces RF interference. It increases the signal-to-noise ratio in wireless audio transmission to more than 110 dB.

HDX is a wideband compander system which compresses the audio signal in the transmitter in a 2:1 ratio (related to dB) to lift it above the inherent noise floor of the RF link. A 110 dB dynamic range signal is thus transmitted with an effective dynamic range of only 55 dB, which is above the 60 dB noise floor of the RF link. In the receiver the signal is expanded in an identical and opposite way in a 1:2 ratio to restore the original signal, at the same time reducing the RF noise to below the noise floor of the receiver.

HDX has been specially developed for high quality radiomicrophone systems.

Note:

Only transmitters and receivers that are equipped with HDX can work correctly with each other. If non HDX equipment was mixed with HDX, the dynamic range would be drastically reduced and the transmission would sound blunt and flat. HDX is permanently active and cannot be switched off.

Wireless transmission systems

With the ew 100 G2 series, Sennheiser puts an end to cable tangles and enables complete freedom of movement. The systems operate exclusively in the UHF band. UHF transmission is extremely reliable and is far less prone to interference than the overcrowded VHF band – harmonics from mains units, fluorescent tubes, refrigerators, computers, etc. are virtually eliminated. Also indoor propagation of UHF radio waves is better than VHF so that the RF power can be kept low – this is also an advantage when using multi-channel systems. Finally, UHF frequency ranges are being approved all over the world for radiomicrophone usage – in some countries licence-free.

There are three transmitter versions: The hand-held transmitter is a complete radiomicrophone in a single unit, the plug-on transmitter converts your favourite wired microphone into a radiomicrophone, the bodypack transmitter can accept a wide range of inputs including: omni-directional or cardioid clip-on microphones, head-worn microphone, guitar/instrument direct input and auxiliary units via the optional CL 2 line input cable.

Correct adjustment of transmitter sensitivity is vital. Too high and you get overmodulation and distortion, too low and you get undermodulation and a noisy signal. Please set the sensitivity correctly for the microphone/usage and check it before every performance to ensure best operation.

Sennheiser miniature clip-on microphones can be attached in various ways: they can, for example, be attached to the hairline or to clothing (e.g. tie or lapel). However it is fixed, please make sure that the microphone is protected against sweat/moisture and make-up.

Squelch

Pilot tone squelch

The transmitter adds a pilot tone to the audio signal. The receiver checks incoming audio signals to see if the pilot tone is present. In the absence of the signal, the receiver's audio output will remain muted, even if a strong RF signal is present.

This prevents strong interfering signals from causing hissing noise in the receiver when the transmitter is switched off.

In order to benefit from this feature, the pilot tone function must be activated on both the transmitter and the receiver. The pilot tone function is factory-preset to "ON" (= activated).

Field strength-dependent squelch

Depending on the strength of the received RF signal, the receiver's audio output is opened or muted. Via the "SQELCH" menu of the receiver, the squelch threshold can be adjusted in three steps (LO, MID, HI).

Diversity reception

The EM 100 G2 receiver operates on the "true diversity" principle:

A receiving antenna receives not only the electromagnetic waves which reach it by a direct path, but also the reflections of these waves which are created in the room by walls, windows, ceilings and fittings. When these waves are superimposed, destructive interference occurs, which can also be called "field strength gaps". Repositioning the receiving antenna can bring a solution. With mobile transmitters, however (which all radiomicrophones are), the "field strength gap" will then occur with a different transmitter position. These "field strength gaps" can only be eliminated with true diversity receivers.

In true diversity, instead of one antenna and one receiver there are now two antennas and two receiver sections. The antennas are spatially separated. By means of a comparison circuit, the receiver section with the strongest RF signal is always switched to the common AF output. The risk of the occurrence of "field strength gaps" in both antennas at the same time is virtually nonexistant.



The receiver display panel shows the active diversity section (I or II) ⑪.



Specifications

System

RF characteristics	
Modulation	wideband FM
Frequency ranges	518–554, 626–662, 740–776, 786–822, 830–866 MHz
Transmission/receiving frequencies	8 channel banks with 4 factory-preset channels each 1 channel bank with 4 freely selectable channels (1440 frequencies, tunable in steps of 25 kHz)
Switching bandwidth	36 MHz
Nominal/peak deviation	± 24 kHz/± 48 kHz
Frequency stability	≤± 15 ppm
AF characteristics	
Noise reduction system	Sennheiser HDX
AF frequency response	40–18,000 Hz
S/N ratio (at 1 mV and peak deviation)	≥ 110 dB(A)
THD (at nominal deviation and 1 kHz)	≤ 0.9 %
General data	
Temperature range	–10 °C to +55 °C
Dimensions of carrying case [mm]	380 x 370 x 70
Weight of carrying case with EM 100 G2	approx. 3100 g
Weight of carrying case with EK 100 G2	approx. 2160 g

Receivers

RF characteristics	**EM 100 G2**	**EK 100 G2**
Receiver principle	true diversity	non diversity
Sensitivity (with HDX, peak deviation)	<2.5 µV at 52 dBA_{rms} S/N ratio	<2.5 µV at 52 dBA_{rms} S/N ratio
Adjacent channel rejection	≥ 65 dB	≥ 65 dB
Intermodulation attenuation	≥ 65 dB	≥ 65 dB
Blocking	≥ 70 dB	≥ 70 dB
Squelch	4 steps: OFF LO: 5 dBµV MID: 15 dBµV HI: 25 dBµV	4 steps: OFF LO: 5 dBµV MID: 15 dBµV HI: 25 dBµV
Pilot tone squelch	can be switched off	
Antenna inputs	2 BNC sockets	–
AF characteristics		
AF output voltage (at peak deviation 1 kHz_{AF})	¼″ (6.3 mm) jack socket (unbalanced): +18 dB_u XLR socket (balanced): +12 dB_u	3.5 mm jack socket: unbalanced: +10 dB_u
Overall device		
Power supply	10.5–16 V DC, nominal voltage 12 V DC	2 AA size batteries, 1.5 V
Power consumption	approx. 200 mA	approx. 130 mA
Power consumption with switched-off receiver	–	≤ 250 µA
Dimensions [mm]	212 x 145 x 38	82 x 64 x 24
Weight	approx. 1100 g	approx. 158 g (incl. batteries)

Transmitters

	SK 100 G2	SKP 100 G2	SKM 100 G2
RF characteristics			
RF output power at 50 Ω	typ. 30 mW		
AF characteristics			
Max. input voltage (at peak deviation)			
Microphone	1.8 V_{rms}, unbalanced	1.2 V_{eff}, unbalanced	–
Line	2.4 V_{rms}	–	–
Input impedance			
Microphone	10 kΩ, unbalanced	10 kΩ, unbalanced	–
Line	1 MΩ	–	–
Overall device			
Power supply	2 AA size batteries, 1.5 V		
Nominal voltage	2.4 V	2.4 V	2.4 V
Max. power consumption at nominal voltage	≤170 mA		
Power consumption with switched-off transmitter	≤250 µA	≤250 µA	≤250 µA
Operating time (with batteries)	> 8 h	> 8 h	> 8 h
Operating time (with BA 2015 accupack)	> 8 h	> 8 h	> 8 h
Dimensions [mm]	82 x 64 x 24	105 x 43 x 43	∅ 50 x 225
Weight (incl. batteries)	approx. 158 g	approx. 195 g	approx. 450g

Microphones

	ME 2	ME 3	ME 4
Transducer principle	condenser	condenser	condenser
Sensitivity	20 mV/Pa	1.6 mV/Pa	40 mV/Pa
Pick-up pattern	omni-driectional	super-cardioid	cardioid
Max. SPL	130 dB SPL	150 dB SPL	120 dB SPL

Microphone heads

	MD 835	MD 845	ME 865
Transducer principle	dynamic	dynamic	condenser
Sensitivity	1.5 mV/Pa	1 mV/Pa	3 mV/Pa
Pick-up pattern	cardioid	super-cardioid	super-cardioid
Max. SPL	150 dB SPL	154 dB SPL	144 dB SPL
Color of identification ring	green	blue	red

Connector assignment

EM 100 G2:
¼″ (6.3 mm) stereo jack plug, unbalanced



EM 100 G2:
¼″ (6.3 mm) mono jack plug, unbalanced



EM 100 G2:
XLR-3F connector, balanced



EM 100 G2:
DC connector for power supply

SK 100 G2:
3.5 mm jack plug



EK 100 G2:
3.5 mm stereo jack plug, unbalanced



EK 100 G2:
3.5 mm mono jack plug, unbalanced



Polar diagrams and frequency response curves of microphones/microphone heads

Polar diagrams of microphones/microphone heads

MD 835



ME 865



ME 3



MD 845



ME 4



Frequency response curves of microphones/microphone heads

MD 835



ME 2



MD 845



ME 3



ME 865



ME 4



Accessories

MD 835	Microphone head for SKM 100 G2 (green identification ring), dynamic, cardioid	
MD 845	Microphone head for SKM 100 G2 (blue identification ring), dynamic, super-cardioid	
ME 865	Microphone head for SKM 100 G2 (red identification ring), condenser, super-cardioid	
MZW 1	Wind- and popshield for SKM 100 G2	
MZQ 1	Microphone clamp for SKM 100 G2	
ME 2	Clip-on microphone for SK 100 G2, condenser, omni-directional	
ME 4	Clip-on microphone for SK 100 G2, condenser, cardioid	
ME 3	Headmic for SK 100 G2, condenser, super-cardioid	
CI 1	Instrument cable for SK 100 G2, with ¼″ (6.3 mm) jack plug	
CL 2	Line input cable for SK 100 G2, with XLR-3F connector	
CL 100	Line input cable for EK 100 G2, with XLR-3M connector	
GA 2	19″ rack adapter	
AM 2	Antenna mount for mounting antennas to the front of the GA 2	
A 1031-U	UHF antenna, passive, omni-directional, can be mounted onto a stand	
AB 2-A	UHF antenna booster, 10 dB gain powered via ASP 2/NT1	518–554 MHz
AB 2-B		626–662 MHz
AB 2-C		740–776 MHz
AB 2-D		786–822 MHz
AB 2-E		830–866 MHz
GZL 1019-A1 / 5 / 10	Antenna cable with BNC connectors	1 m / 5 m / 10 m
ASP 2	Antenna splitter, 2 x 1:4, passive, for connecting four EM 100 G2 to two A 1031-U/AB 2	
NT 1	Mains unit for ASP 2	
DC 2	DC power adapter, for external 12 V DC powering of SK 100 G2 (instead of two AA size batteries)	
BA 2015	Accupack for EK 100 G2, SK 100 G2, SKP 100 G2, SKM 100 G2	
L 2015	Charger for BA 2015 accupack	
CC 2	Carrying case for ew 100 G2 system	
KEN	8 color-coded identification caps for SKM 100 G2	

Manufacturer declarations

Warranty regulations

The guarantee period for this Sennheiser product is 24 months from the date of purchase. Excluded are accessory items, rechargeable or disposable batteries that are delivered with the product; due to their characteristics these products have a shorter service life that is principally dependent on the individual frequency of use.

The guarantee period starts from the date of original purchase. For this reason, we recommend that the sales receipt be retained as proof of purchase. Without this proof (which is checked by the responsible Sennheiser service partner) you will not be reimbursed for any repairs that are carried out.

Depending on our choice, guarantee service comprises, free of charge, the removal of material and manufacturing defects through repair or replacement of either individual parts or the entire device. Inappropriate usage (e.g. operating faults, mechanical damages, incorrect operating voltage), wear and tear, force majeure and defects which were known at the time of purchase are excluded from guarantee claims. The guarantee is void if the product is manipulated by non-authorised persons or repair stations.

In the case of a claim under the terms of this guarantee, send the device, including acces-sories and sales receipt, to the responsible service partner. To minimise the risk of transport damage, we recommend that the original packaging is used. Your legal rights against the seller, resulting from the contract of sale, are not affected by this guarantee.

The guarantee can be claimed in all countries outside the U.S. provided that no national law limits our terms of guarantee.

CE Declaration of Conformity

CE 0682

This equipment is in compliance with the essential requirements and other relevant provisions of Directives 1999/5/EC, 89/336/EC or 73/23/EC. The declaration is available on the internet site at www.sennheiser.com.

Before putting the device into operation, please observe the respective country-specific regulations!

Batteries or rechargeable batteries

The supplied batteries or rechargeable batteries can be recycled. Please dispose of them as special waste or return them to your specialist dealer. In order to protect the environment, only dispose of exhausted batteries.

WEEE Declaration

Your Sennheiser product was developed and manufactured with highquality materials and components which can be recycled and/or reused. This symbol indicates that electrical and electronic equipment must be disposed of separately from normal waste at the end of its operational lifetime.

Please dispose of this product by bringing it to your local collection point or recycling centre for such equipment. This will help to protect the environment in which we all live.

Sennheiser electronic GmbH & Co. KG
30900 Wedemark, Germany
Phone +49 (5130) 600 0
Fax +49 (5130) 600 300
www.sennheiser.com

Printed in Germany Publ. 02/06 090608/A2